

STEP-BY-STEP GUIDE


StippleCrete



What do you need:

🔧 Tools & Consumables	📄 Products	📈 Difficulty
<ul style="list-style-type: none">• Mechanical Mixer• Block brush• PVA paint roller• Mist Sprayer	<ul style="list-style-type: none">• CemBond• StippleCrete• SiliconSeal (optional)• Final Sealer of Choice (optional)	★ ★ ☆ ☆ ☆

The system:



STEP-BY-STEP GUIDE

StippleCrete



1. All applicable surfaces to be structurally sound and free from grease, oil, wax, wall paper glue, dust or anything that might interfere with adhesion. Remove dust and loose defective paint if any. Important that the wall is also flat and smooth. Use a stiff mix to fill imperfections, cracks and holes in the brickwork ensuring that it is finished flush with the surrounding surface.



2. Allow this to dry and then using a rubbing brick rub the entire surface so as to remove all high spots before applying StippleCrete. Surfaces should be primed with 2 coats of a solution of 1 volume CemBond, and 5 volumes of water.



3. For normal texture: 2 volumes StippleCrete to 1 volume water.



4. Wet the brush or broom and shake off excess water. Dip the brush in the StippleCrete mixture and liberally apply to the wall from bottom to top. Make sure all small holes and indentations are filled. If further texture is required, use block brush to stipple.



5. Work from one architectural feature to another keeping a wet edge in material to prevent unsightly dry joints. Do not come back to patch. Clean splashes and over-brushing at the end of each day.



6. Following the day of application, cure by wetting all completed work 3 times during the day, to ensure hardness and durability. Always cure from bottom to top in order to avoid water run marks and colour variations.