

# SiliconSeal Datasheet

### September 2019

Page 1 of 3

A colourless, low viscosity, penetrating liquid for application to masonry or concrete surfaces. SiliconSeal is supplied ready for application by brush, roller or spray. SiliconSeal penetrates the pore structure to a depth of about 10mm. Masonry treated in this way can still "breathe" and moisture can dry out through the surface.

#### **Technical Data**

Туре	Penetrative solvent-based sealer
Colour	Transparent
Paintable	2 - 5 days
Final cure	7 - 14 days
Application temperature (ambient)	5°C to 30°C
Substrate temperature	5°C to 30°C
UV resistance	Stable
Density	0.66kg/litre
Protection during application	Protect glass and metal surfaces
Safety	See MSDS

#### Purpose

SiliconSeal greatly reduces the water absorption of concrete, clay bricks, natural stone, fibre cement and plaster. SiliconSeal can also be used for the prevention of rising damp in brick walls by pumping the fluid into previously drilled holes along the course immediately above the faulty damp-proof membrane.

#### **Applications**

Surface coating for building restoration and protection against spalling, cracking, efflorescence and fungal growth. SiliconSeal is a wet-on-wet application and should be applied until the substrate is properly saturated.

#### Colours

An absolutely clear treatment which does not darken or change the colour of the surface to which it is applied.

#### Specifying

#### Surface treatment:

SiliconSeal applied liberally by brush, roller or spray, at least 2 coats wet on wet. SiliconSeal should be applied to a substrate to a point of saturation (until surface absorbs no more). Be sure to remove any 'pooled' SiliconSeal, do not allow this to dry on the surface. SiliconSeal is not film building, but rather crystalline in structure for water repellence and in certain applications it should be over coated with a film forming sealer to stop dirt retention i.e. wet areas, children's rooms or wherever a wall could get dirty.

#### Damp-course repair:

One course of bricks at damp-proof course level to be drilled and saturated with SiliconSeal. All in strict accordance with the manufacturer's instructions.

#### Specimen finish

A trial area should be treated on-site for the architect or engineer's approval.

Cemcrete provides a comprehensive technical service based on over 4 decades of experience in the field of surface applications and cement technology. Cemcrete believes, to the best of its knowledge, that the information contained herein is true and accurate at the date of issuance and is subject to change without prior notice. For further clarification of these instructions, contact Cemcrete.



# SiliconSeal Datasheet

## September 2019

Page 2 of 3

### Suitable surfaces

Concrete, cement plaster, mortar, sandstone, clay- and cement bricks, gypsum plaster, asbestos, cement, terrazzo and coloured cement finishes.

#### Site Work

#### Storage

Store at room temperature in unopened drums for a maximum of 4 months from date of invoice.

#### Weather

Do not apply during wet or freezing weather conditions.

#### Surface preparation

Surfaces should be clean and dry. Concrete, plaster or cement bricks should be at least 1 month old.

#### Masking

Mask all adjacent surfaces, especially glass or aluminium to prevent etching or staining.

#### Mixing

Rock drum in inverted position for a few minutes before opening and stir contents thoroughly before use.

#### Application

#### Surface treatment:

Apply liberally from bottom to top using a brush, roller or low pressure spray to dry surfaces.

#### Damp-course repair:

Strip plaster from brickwork and drill at an angle of 30 to 60 degrees at least 50mm into the brick about 100mm apart. The liquid can be gravity fed using a funnel into each brick in the course immediately above the faulty damp proof-course. If pressure injection is used, 30 - 50psi is common. Inject until SiliconSeal bleeds back through the face of the brick. Wash equipment in mineral turps. When re-applying plaster cut control joints through to the brick at DPC level.

#### Curing

SiliconSeal should be allowed to dry for at least 2 - 5 days depending on the weather to allow the solvent to fully evaporate. The best time to overcoat SiliconSeal with a sealer or paint would be between 2 - 5 days after application. Application before or after this window will result in adhesion problems. Full cure takes place after 7 - 14 days.

#### Coverage

Face bricks 6m<sup>2</sup>/litre Porous bricks 3m<sup>2</sup>/litre Concrete 4m<sup>2</sup>/litre These figures are approximate and will vary according to the texture and porosity of the particular surface.

#### Packaging

Available in 1. 5 & 25 litre containers.

Cemcrete provides a comprehensive technical service based on over 4 decades of experience in the field of surface applications and cement technology. Cemcrete believes, to the best of its knowledge, that the information contained herein is true and accurate at the date of issuance and is subject to change without prior notice. For further clarification of these instructions, contact Cemcrete



# SiliconSeal Datasheet

September 2019

Page 3 of 3

### Manufacturer's Warranty

Cemcrete warrants that the products manufactured by it shall be free from material defects and will be consistent with its normal high quality. Should any of the products be proven defective, the liability to Cemcrete shall be limited to replacement of the product ex-factory. Cemcrete makes no warranty as to merchantability or fitness for a particular purpose and this warranty is in lieu of all other warranties expressed or implied. The user shall determine the suitability of the product for his intended use and assume all risks and liability in connection therewith.

Cemcrete provides a comprehensive technical service based on over 4 decades of experience in the field of surface applications and cement technology. Cemcrete believes, to the best of its knowledge, that the information contained herein is true and accurate at the date of issuance and is subject to change without prior notice. For further clarification of these instructions, contact Cemcrete.

Johannesburg Head Office 8 Telford Street Industria 011 474 2415

Johannesburg Showroom 227 Jan Smuts Avenue Parktown North 011 447 3149

Centurion Showroom & Warehouse 15 Coachmen's Park 26 Jakaranda Street, Centurion 012 653 6808

Cape Town Showroom & Warehouse Eagle Park, cnr Bosmansdam & Omuramba Roads, Montague Gardens 021 555 1034